

# MAINTENANCE - ENTRETIEN



To enhance the durability and appearance, we recommend following our care instructions regularly.

The umbrella should never be used in strong wind or rainy conditions. An open umbrella should never be left unattended. The umbrella should be protected against blurring or damage by using its protection cover. The protection cover can be placed over the umbrella and pole. Store the umbrella in a dry place when not in use.

## FRAME & BASE

Clean the aluminium frame with a damp cloth, mild soap and water. Do not use any sharp tool to avoid scratches.

## CANOPY

Before use, you can apply an invisible film to make the canopy stain and water repellent by using a textile protector.

You can maintain and clean your canopy by following a few simple steps:

- Brush off loose dirt before it becomes embedded in the fabric.
- Hose down.
- Spot clean soon after stains occur with water and mild soap or textile cleaner (no detergents). Use a soft bristle brush to clean.
- Allow soap to soak in.
- Rinse thoroughly.
- Always let the canopy air dry completely before storing or covering.

Machine wash in cold water. Depending on wash load size, use normal amounts of mild laundry detergent and add 1 cup of bleach. Allow fabric to air dry.

NEVER SUBJECT TO EXCESSIVE HEAT, STEAM PRESS OR TUBLE DRY AS THE FABRIC WILL SHRINK.



### Maintenance set:

- 2 scrubbing sets
- 3 application cloths
- 1 textile protector 750 ml
- 1 textile cleaner 750 ml

Pour améliorer la durabilité et l'apparence, nous vous recommandons de suivre nos instructions d'entretien régulièrement.

Le parasol ne doit jamais être utilisé dans des conditions fortes ou pluvieuses. Un parasol ouvert ne doit jamais être laissé sans surveillance. Le parasol doit être protégé contre le flou ou les dommages en utilisant sa housse de protection. Rangez le parasol dans un endroit sec lorsqu'il n'est pas utilisé.

## STRUCTURE & SOCLE

Nettoyez la structure et le socle en aluminium thermolaqués avec un chiffon humide, du savon doux et de l'eau. N'utilisez aucun outil pointu pour éviter les rayures.

## TOILE

Avant la première utilisation, vous pouvez appliquer un film invisible pour rendre la toile anti-taches et hydrofuge en utilisant un protecteur textile. Vous pouvez entretenir et nettoyer votre toile en suivant quelques étapes simples.

- Brossez la saleté avant qu'elle ne s'incruste dans le tissu.
- Arrosez.
- Nettoyez les taches après l'apparition des taches avec de l'eau et un savon doux ou un nettoyant textile (sans détergents). Utilisez une brosse à poils doux pour nettoyer.
- Laissez le savon pénétrer.
- Rincez abondamment.
- Laissez toujours la toile sécher complètement à l'air avant de la ranger ou de la recouvrir.

Lavage en machine à l'eau froide. Selon la taille de la charge de lavage, utilisez des quantités normales de détergent à lessive doux et ajoutez 1 tasse d'eau de Javel. Laissez le tissu sécher à l'air.

NE JAMAIS SOUMETTRE À UNE CHALEUR EXCESSIVE, À UNE PRESSION À LA VAPEUR OU À UN SÉCHAGE EN TUMBLE COMME LE TISSU RÉTRACTURE.

### L'ensemble de maintenance comprend:

- 2 sets de récurage
- 3 chiffons d'application
- 1 protecteur textile 750 ml
- 1 nettoyant textile 750 ml